



KitchenAid KHM512ER Beater Rings Replacement

Replacing the beater rings on the KitchenAid KHM512ER.

Written By: Brad Daniels



INTRODUCTION

Are your beaters not staying in? You may need to replace the beater rings.



TOOLS:



- [iFixit Opening Tools](#) (1)
 - [Phillips #2 Screwdriver](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Beater Rings





- Insert the back of a plastic opening tool into one of the beater holes
- Apply force to pull the circular plastic part off.
- If necessary, use the other side of the plastic opening tool to pry the circular plastic part off.

Step 2





- Use a Phillips #2 screwdriver to remove the two 20mm screws holding the bottom plastic piece in place.
- Remove the bottom plastic piece using a plastic opening tool.

Step 3




- Using a Phillips 2 screwdriver, remove the three 20.0mm screws holding the motor assembly in place.
- Use your hands to remove the motor assembly.



Step 4



- Firmly grip the motor in your hand. Using pliers, pull the connectors off the motors.

 Some force may be required. Be careful not to cut yourself on any electrical components.

Step 5



- Lie the motor down flat on a table.
- Using a pair of tweezers, remove the ring from the plastic knob.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 04:19:07 AM.